



Support block is mounted below the top rail of gate to prevent vertical deflection. IT SHOULD NOT MAKE CONTACT WITH THE GATE OR INTERFERE WITH IT SWINGING CLOSED. Field installations: simply mount the block at least 45mm BELOW the closed bar.



Intrepid Safety Products B.V. Wolfstraat 5 4561 PL Hulst

Safety Gate

www.isp-products.com

Edition 2

Sheet 1/1